Flood prediction using a distributed flow routing model:

1K-FRM-event ver. 1.34

September 22, 2016

Yasuto TACHIKAWA and Tomohiro TANAKA

Dept. of Civil and Earth Resources Eng., Kyoto University, Kyoto 615-8540, Japan tachikawa@hywr.kuciv.kyoto-u.ac.jp

Introduction

1K-FRM-event is a distributed flow routing model based on kinematic wave theory to predict river flood discharge. The model is used to predict flood propagation with the input of runoff generation. The distributed flow routing model was used in Japan and also various southeast Asian region to estimate river discharge using the HydroSHED 30 second digital elevation model and flow direction data.

Theory

The flow direction is defined using the eight-direction method which assumes the flow direction to the steepest downward slope to immediate neighboring cell. The forcing data is runoff generation intensity at each grid cell and the runoff generation data are routed by the kinematic wave equations at each flow element in accordance with the flow direction information. The basic form of the kinematic-wave equations utilized in 1K-FRM model are:

$$\frac{\partial Q}{\partial x} + \frac{\partial A}{\partial t} = q_L(x,t) \tag{1}$$

$$Q = \alpha A^m, \alpha = \frac{\sqrt{i_0}}{n} \left(\frac{1}{B}\right)^{m-1}, m = \frac{5}{3} \tag{2}$$

where A(x, t) is the flow corss-sectional area, Q(x, t) is the flow discharge, $q_L(x, t)$ is the runoff generation inflow per unit length, i_0 is the bed slope, n is the Manning's roughness coefficient, and B is the width of the flow. Eq. (1) is the continuity equation derived from the law of mass conservation within a control volume. Eq. (2) is derived from the momentum equation with the kinematic wave flow assumptions.

How to use 1K-FRM

1K-FRM-event is a distributed flow routing model based on kinematic wave theory. The source programs are coded using C++ language and works under Microsoft windows environment and the Linux environment. All program source codes and input topography data in the Asian region are provided from the home page of Hydrology and Water Resources Research Laboratory at Department of Civil and Earth Resources Engineering, Kyoto University:

http://hywr.kuciv.kyoto-u.ac.jp/products/1K-DHM/1K-DHM.html

The input topography data is generated using HydroSHED 30 second digital elevation model and flow direction data. Forcing data to drive 1K-FRM-event such as runoff generation or

precipitation is supposed to be hourly gridded data. At first, a method to develop topography data for 1K-FRM-event is described. Then, by using the developed data, an example of rainfall-runoff simulation using 1K-FRM-event is demonstrated. Figure 1 shows entire structure of the coordinate system used for 1K-FRM-event flow routing simulation.




Figure 1: Geographic relation of flow routing simulation area and forcing data grid region.

1. Preparation of Topographic Data for 1K-FRM-event

1) Hydroshed2topo

Hydroshed2topo is a program to generate input topography data for 1K-FRM-event, which is obtained from 1K-FRM homepage.

2) Input data

The topographic data for a flow routing model 1K-FRM-event is generated by using the HydroSHED (http://hydrosheds.cr.usgs.gov/) 30-second digital elevation and flow direction data. The DEM and flow direction data with ESRI grid format data for entire Asia (55E,-10S to 180E, 60N) from HydroSHED were downloaded and they were converted to short integer 2-bite binary data format to reduce the file size. These two files:

as_dem_30s_clipped_55—10-180-60.bin (246MB) as dir 30s clipped 55—10-180-60.bin (246MB)

are obtained from 1K-FRM homepage. These two data are input files for hydroshed2topo.

3) Parameter data

All Necessary topographic input files to run the 1K-FRM-event are created by executing the hydroshed2topo.cc. The program creates additional ESRI ASCII files and those files can be imported to ArcGIS to prepare maps of the study area. First, you need to specify the study area by editing the parameter data file

hydroshed2topo/clipArea.dat

This file is a text data file. The study area is determined as a rectangular region by setting longitude and latitude as shown in Figure 2.

- The first row specifies the number of columns for the study region. The value must be an integer value.
- The second row specifies the number of rows for the study region. The value must be an integer value.
- The third row specifies Longitude (degree) of South West (lower left) corner of the study area. The value is a real value.
- The forth row specifies Latitude (degree) of South West (lower left) corner of the study area. The value is a real value.

The grid size is supposed to 30 second. The longitude (second) of j-th cell center is set as follows:

longitude = (int)(SWlon*3600) + 30*j + 15;

latitude = (int)(SWlat*3600) + 30*i + 15;




Figure 2: Setting study area. An example of clipArea.dat.

4) Generation of topographic information for 1K-FRM-event

Compile hydroshed2topo.cc and run hydroshed2topo.exe.

5) Output files

All output files used for the 1K-FRM-event are created in the folder:

hydroshed2topo/output

The files generated are below:

• **modDem.bin**: This is the corrected (pit removed) elevation information of the study area. The data was written in real 4-byte binary data format.




Figure 3: A sample of modem.bin.

• **flowDir.bin**: Flow direction information. The direction convention is shown in Figure 3. The data format is integer 4-bite binary.




Figure 4: A sample of flowDir.bin.





Figure 5: Flow direction specified by the integer value.

• **flowAcc.bin**: Flow accumulation information. The data format is integer 4-bite binary.



• **riverNum.bin**: Each river basin is numbered starting from 1 and then each grid cell is assign a value corresponding to the basin number which the cell is belongs to. The data format is integer 4-bite binary.




Figure 7: A sample of riverNum.bin.

• **riverNumList.txt**: This is a text file which contains:

Column 1: river basin number of the study area, Column 2: the basin area (acmulated number of grids). Column 3: column number starting from 1 (starting from West), Column 4: row number starting from 1 (starting from South), Column 5: longitude (second), Column 6: latitude (second), Column 7: longitude (degree), and Column 8: latitude (degree)

If you want to calculate the discharge data only at some selected basins using 1K-FRMevent or 1K-FRM, you can delete all the other basins from this text file and keep only the necessary basins.

All data begins from the South-West grid and lining to East, then, moving to the North in the next line, which are typical GrADS data format. Sample GrADS control files are attached in hydroshed2topo to visualize the data.

1 5 10 59 497085 129555 138.079 35.9875 2 3 14 59 497205 129555 138.113 35.9875 3 4 16 59 497265 129555 138.129 35.9875 4 4 17 59 497295 129555 138.137 35.9875 5 4 18 59 497325 129555 138.146 35.9875 ...

Figure 8: An example of riverNumList.txt.

Additional files are also created, which are ESRI ASCII files to be imported to ArcGIS to visualize the study region:

- **cutDem.asc**: The DEM data for the study region. This is the original data clipped for the study region.
- **cutDir.asc**: The DIR data for the study region. This is the original data clipped for the study region.
- **modDem.asc**: The DEM data for the study region. This is the corrected (pit removed) elevation information of the study area, which corresponds to **moDem.bin**.
- flowDir.asc: The Flow Direction data for the study region, which corresponds to flowDir.bin.
- flowAcc.asc: Flow accumulation value information, which corresponds to flowAcc.bin.
- riverNum.asc: The river basin numbers of the study area, which corresponds to riverNum.bin.
- **distance.asc**: The distance from the river mouth.

2. Preparation of Forcing Data

It is necessary to create a text file of effective hourly forcing data (spatially distributed lateral input data to slope and river such as rainfall intensity or runoff generation intensity data). If the data duration is shorter than simulation time, remaining rainfall is assumed to zero. A part of a sample data file is shown in Figure 9. The rainfall data file name is "rain.dat" and should be placed at

1k-frm-event/input/rain.dat

The first line of "rain.dat" is Year, Month, Day, Hour, Column Number, and Row Number of spatially gridded rainfall data. From the next line, rainfall intensity values (mm/hr) are stored beginning from the North-West grid and lining to East, then, moving to the South in the next line. Each data is delimited by white space characters (SPACE, TAB, or CR). You can change the rainfall intensity data for your study purpose.

1979 12 1 1 5 6
0.1 0.2 0.3 0.4 0.5
0.6 0.7 0.8 0.9 1.0
1.1 1.2 1.3 1.4 1.5
1.6 1.7 1.8 1.9 2.0
2.1 2.2 2.3 2.4 2.5
2.6 2.7 2.8 2.9 3.0

Figure 9: Part of rain.dat. The 1st Row is: Year, Month, Day, Hour, Column Number, Row Number. From the 2nd to 7th Rows, effective rainfall intensities (5 columns and 6 rows) in mm/hr are stored.

The geographic structure is shown in Figure 10. The rainfall intensity data represents the intensity of each grid center. The time interval of the rainfall intensity must be hour. Figure 11 shows the relation between the rainfall-runoff simulation region and rainfall grid region. For runoff simulation, the nearest grid of rainfall intensity is selected.




Figure 10: Structure of coordinate of the rainfall grid system.

The grid size of forcing data is set in the parameter setting file for 1K-FRM-event. The grid center of longitude (degree) and latitude (degree) of j-th column and i-th row for input data are set as follows:

longitude = ROF_WLON + j*Delta_x; // set longitude
latitude = ROF_SLAT + j*Delta_y; // set latitude




Figure 11: Geographic relation of rainfall-runoff simulation area and rainfall grid region.

3. Flow Routing Simulation Using 1K-FRM-event

Figure 11 shows the geographic relation of the rainfall-runoff simulation area and the rainfall grid region for the example data. The procedures for runoff simulation are as follows:

1) **Topography data setting**: Copy the topographic information files (above mentioned five files)

from hydroshed2topo/output/ to 1k-frm-event/topoData/

2) Rainfall data setting: Set the rain data and place rainfall data file at

1k-frm-event/input/rain.dat. (The file name must be rain.dat.)

3) Runoff simulation parameter setting: Edit the runoff simulation parameter file

1k-frm-event/param-event.dat

by using any text editor. Delimiter of each data is white space characters.

120	Number of columns of the study area
60	Number of rows of the study area
138.0	Longitude (degree) of South West corner of the study area
35.5	Latitude (degree) of South West corner of the study area.
5	Number of columns of the input forcing data
6	Number of rows in the input forcing data
0.1875	Input data grid size of x-direction (degree)
0.1875	Input data grid size of y-direction (degree)
137.75	West corner longitude of input data (degree)
35.25	South corner latitude of input data (degree)
10	Simulation duration (days)
600	simulation time step (sec)
20	number of spatial divisions
0.65	0.5 < theta <= 1.0
0.5	Manning's roughness coefficient for slope (m-s unit)
0.03	Manning's roughness coefficient for river (m-s unit)
250	grid accumulated number to differentiate slope and river
0.0	Initial runoff height for kinematic wave model (mm/hr)

Figure 12: An example of param-event.dat.

The parameter values to set in param-event.dat are as follows:

• From 1 st row to 4 th row, the parameters of the study region is specified:				
int Col=120	// number of column for study area.			
int Row=60	// number of row for study area.			
double SWLON=138.0	// Longitude (degree) of north west corner of the study area.			
double SWLAT=35.5	// Latitude (degree) of north west corner of the study area.			

• From 5^{th} row to 10^{th} row, the parameters of the rainfall data is specified:

int ROFnum_col = 5	// Number of column of input rainfall data
int ROFnum_row = 6	// Number of row of input rainfall data
double Delta_x = 0.1875	// Input data grid size of x-direction (degree)
double Delta_y = 0.1875	// Input data grid size of y-direction (degree)
double $ROF_WLON = 137.7$	75 // West corner longitude of input data (degree)
double ROF_SLAT = 35.25	// South corner latitude of input data (degree)

• The 11^{th} row is a parameter to determine the simulation term. int Ndays = 10 // Simulation duration (days) • From 12th row to 14th row, the parameters for the finite difference condition are specified. Usually, you do not need to change these parameter values.

int Time_Step = 600	// Simulation time step (sec)
int Nspace $= 20$	// Number of spatial divisions
double Theta = 0.65	// weight value $0.5 <$ theta ≤ 1.0

• From 15th row to 17th row, the parameters for the kinematic wave model are specified. double Man_slope = 0.5 // Manning's roughness coefficient for slope (m-s unit)double Man_channel = 0.03 // Manning's roughness coefficient for river (m-s unit) int Threshold_basin = 250 // grid accumulated number to differentiate slope and river

• The 16th row is a parameter to determine the initial condition. double initial ROF = 0.0 // Initial runoff height (mm/hr)

4) Rainfall-runoff simulation

Move to the folder "/project/1k-frm-event" and run

"1k-frm-event.exe"

All runoff simulation results are created in

1k-frm-event/output

The files created are below:

- **dischargeDaily.bin:** The file contains the average daily flow (m^3/sec) .
- **dischargeHourly.bin:** The file contains the hourly flow (m^3/sec) .
- **dischargeHourlyMaxInDay.bin:** The file contains the maximum hourly flow value for each day (m³/sec).

The data are stored in GRADS binary data format and can be visualized using GRADS (<u>http://www.iges.org/grads/</u>). All data arranges from west to east at the South row, then North row. GrADS control file:

- flowAnalysisGradsDaily.ctl
- flowAnalysisGradsHourly.ctl

are attached. A sample program is also attached in ./output:

- pointdata-event.cc

which extracts time series ascii data from the above binary data.

5) Compile

If you want to change the source code, compile a modified code using:

• Linux environment: The executable is created by using the GNU g++ compiler as following command

% g++ -o 1k-frm-event 1k-frm-event.cc cellfunc-event.cc roffunc-event.cc

For Intel C++ compiler of Linux version

% icc -o 1k-frm-event 1k-frm-event.cc cellfunc-event.cc roffunc-event.cc

• MS Windows environment: Microsoft Visual Studio 2008 or 2010 with C++ compiler is useful. You can download a free version of Visual C++ Express Edition 2008 or 2010 from Microsoft web site.

The solution file *Ik-frm-event.sln* should be created according to the Microsoft Visual Studio to use Visual Studio environment. You can also use the command prompt window of the Microsoft Visual Studio. In this case, after opening the command prompt window, you can compile the program as:

% cl 1k-frm-event.cc cellfunc-event.cc roffunc-event.cc

For Intel C++ compiler of windows version

c:\> icl 1k-frm-event.cc cellfunc-event.cc roffunc-event.cc

4. Output Data Analysis

4.1 Visualization of time and space change of discharge using GRADS

GRADS is a free visualization software mainly used by meteorologists. The software works on Windows and Linux/Unix environment. GRADS is available from <u>http://www.iges.org</u>/grads/.

You can use an example of GRADS control files "flowAnalysisGradsDayly.ctl" and "flowAnalysisGradsHourly.ctl" in "/project/misc/gradsControlFiles". Please see the detail information at the web page. Figure 13 is a spatial distribution of discharge at the study region.




Figure 13: Spatial view of simulated discharge using GrADS.

4.2 Visualization of time and space change of discharge using makeImage.exe and IrfanView

If you do not have GrADS, you can generate PPM format image files and see it using a free image viewer IrfanView. The procedure to see the animation of time and space change of discharge is as follows:

- (1) Run the image generation program makeppm.exe, which is downloaded from 1K-FRM home page. This program reads the GrADS format output hourly discharge data **dischargeHourly.bin** and generate PPM format image files under image folder. To run the program,
 - 1-1) Open the folder "/project/1k-frm-event"
 - 1-2) Click "makeppm.exe"
 - 1-3) Image files are gerenated under "/project/1k-frm-event/image/".

(2) Install IrfanView. This is a very popular free image viewer. Click

misc/irfanview/irview428_setup.exe

The viewer is installed and you will find the icon on your MS-Windows desktop.

(3) Click the IrfanView icon and select [File]→[Slideshow]. Then, set the location of PPT image file. You can enjoy the animation.

File Edit Image Options View Help Image Image Options View Help Image Image Image Image Image Image Image Image Image Image Image Image Image Image <th></th> <th></th> <th></th>			
Set slideshow time interva	al	Set image files folder	×
Slideshow options	Play Slideshow Cancel Slideshow start! P Snow text: \$D\$F \$X	ファイルの場所(): image ア 1 価値目 名前・ 1_discharge ppm 2011/02/23 16:18 PPM ファイル 2_discharge ppm 2011/02/23 16:18 PPM ファイル 3_discharge ppm 2011/02/23 16:18 PPM ファイル 4_discharge ppm 2011/02/23 16:18 PPM ファイル 5_discharge ppm 2011/02/23 16:18 PPM ファイル 5_discharge ppm 2011/02/23 16:18 PPM ファイル 5_discharge ppm 2011/02/23 16:18 PPM ファイル 7_discharge ppm 2011/02/23 16:18 PPM ファイル 7/0/28 16:18 PPM ファイル 1 7/0/28 16:18 PPM ファイル 1 7/1/07 All files (**) ▼ 1	
Image: Not 1 Hide mouse cursor Image: Close InfaniView after last slideshow file Play mode: Image: Play in full screen mode (current monitor) Image: Full screen options Load filenames from TXT file Save filenames as TXT file Save slideshow as EXE/SCR Burn slideshow to CD Image: Image: Close Street Screen (for 'Add all')	\$D = file folder, \$F = file name \$X = file index, \$Ex = EXIF, \$Ix = IPTC Help C Play in Window mode: X-pos: 0 Y-pos: 0 Width: 2000 Height: 2000 ↓ Centered Preview image	Add Remove Move up Slideshow files: (96) Add all Remove all Move down Sott files ChomeNachkawaV2011%## VITVprojectVIk-dmrevent/imageV 1. discharge.ppm C-VhomeVachkawaV2011%## VITVprojectVIk-dmrevent/imageV 2. discharge.ppm C-VhomeVachkawaV2011%## VITVprojectVIk-dmrevent/imageV 3. discharge.ppm C-VhomeVachkawaV2011%## VITVprojectVIk-dmrevent/imageV 4. discharge.ppm C-VhomeVachkawaV2011%## VITVprojectVIk-dmrevent/imageV 6. discharge.ppm C-VhomeVachkawaV2011%## VITVprojectVIk-dmrevent/imageV 6. discharge.ppm C-VhomeVachkawaV2011%## VITVprojectVIk-dmrevent/imageV 6. discharge.ppm C-VhomeVachkawaV2011%## VITVprojectVIk-dmrevent/imageV 1. discharge.ppm C-V	

Figure 14: IrfanView Slideshow setting.

(4) Another method to view the animation is to select [FIle]→[Open], select the image folder and click the first image. Then, select [View]→[Start/Stop automatic viewing]. You can select [View]→[Display option (window mode)] to enlarge the image.

4.3 Time series of discharge data at specific point

The procedures to extract the time series of discharge data at the specific point is as follows:

- (1) Run the time series extraction program pointdata.exe. This program reads the GRADS format output hourly discharge data **dischargeHourly.bin** and generates text format time series data under /output. To run the program,
 - 1-1) Open the folder "1k-frm-event".
 - 1-2) Click "pointdata.exe".
 - 1-3) You will be asked to input the column and row number to extract the data. To determine the column and row number, it is useful to see the accumulated catchment data "/project/hydroshed2topo/output/ESRIBasin.asc to examine the discarge with large catchment size. The row and column number begins from the North West corner starting from 1.
 - 1-4) The extracted data is generaated under $\label{eq:lasses} 1-4$ model. The first column of the data is time count (hour) and the second column is discharge (m³/sec).

1	0.0882515
2	0.653777
3	2.2653
4	7.35936
5	14.4867
6	20.414
7	25.6387
8	32.4114
9	43.8638
10	55.3801

Figure 15: An example of time series discharge data extracted by using pointdata-event.exe.

(2) To draw the hydrograph, you can use Excel or GnuPlot (<u>http://www.gnuplot.info/</u>).

Case Study

A river routing model 1K-FRM was applied to throughout Indochina to detect the change of river discharge for three 25-year periods (present, near future, and future experiments). The input to the river routing model was the runoff generation data projected by the 20-km AGCM (MRI-AGCM3.2S), the 60-km AGCM (MRI-AGCM3.2H), and MIROC5 (Duong et al., 2014). Figure 16 shows maps of the estimated change ratio of the mean of the annual maximum discharge in the far future climate experiment (2075–2099) to that of the present climate experiment (1979–2003) using the 20-km AGCM. The figure also shows the results of the statistical significance analysis of these changes. The results obtained by using the 20-km AGCM and the 60-km AGCM show similar results; both indicate a statistically significant increase in the annual maximum discharge in the Irrawaddy Rivers. In contrast, the result obtained by using MIROC5 shows a statistically significant increase in discharge in the large region of Indochina.

Figure 17 shows similar maps for the mean of the annual minimum daily discharge. All three climate models indicate increasing trends in the upper reaches of the Salween and Mekong Rivers. However, in the central regions of Vietnam, the annual minimum daily discharge projected by using the 20-km AGCM and the 60-km AGCM show a decrease tendency, while the one using MIROC5 shows an increase tendency. Both changes are statistically significant at a 5% level, indicating that the uncertainty in the model ensembles for the annual minimum daily discharge is large.




Fig. 16: (a) Change ratio of the mean of the annual maximum discharge of the far future climate experiment (2075–2099) to the present (1979–2003) using the 20-km AGCM (MRI-AGCM3.2S) and (b) statistical significant change at the 5% level (Duong *et al.*, 2014).




Fig. 17: Similar figures for the mean of the annual minimum discharge (Duong et al., 2014).

References

Hydrology and Water Resources Research Laboratory, Department of Civil and Earth Resources Engineering, Kyoto University: 1K-FRM/DHM, A distributed flood routing model and distributed hydrologic model based on kinematic wave theory using HydroSHED topography data

http://hywr.kuciv.kyoto-u.ac.jp/products/1K-DHM/1K-DHM.html

- Manee, D., Y. Tachikawa and K. Yorozu: Analysis of hydrologic variable changes related to large scale reservoir operation in Thailand, Journal of Japan Society of Civil Engineers, Ser. B1 (Hydraulic Engineering), 71(4), I_61-I_66, 2015.
- Duong, D. T. Duong, Y. Tachikawa, K. Yorozu : Changes in river discharge in the Indochina Peninsula region projected using MRI-AGCM and MIROC5 datasets, Journal of Japan Society of Civil Engineers, Ser. B1 (Hydraulic Engineering), 70(4), I_115-I_120, 2014.
- Hunumumbura, P. B. and Y. Tachikawa: River discharge projection under climate change in the Chao Phraya River Basin, Thailand, using the MRI-GCM3.1S dataset, Journal of the Meteorological Society of Japan, 90A, 137-150, 2012, DOI:10.2151/jmsj.2012-A07.
- Hanittinan, P., Y. Tachikawa, Y. Ichikawa, K. Yorozu: Evaluation of future river discharge uncertainties in the Indochina Peninsula simulated by multi-physics ensemble experiments using two-way ANOVA, Journal of Japan Society of Civil Engineers, Ser. B1 (Hydraulic Engineering), 72(4), I_13-I_18, 2016.
- Tanaka, T. and Y. Tachikawa: Testing the Applicability of a Kinematic Wave-based Distributed Hydrologic Model in Two Climatically Contrasting Catchments, Hydrological Sciences Journal, DOI:10.1080/02626667.2014.967693, 2015
- Wichakul, S., Y. Tachikawa, M. Shiiba and K. Yorozu: River discharge assessment under a changing climate in the Chao Phraya River, Thailand by using MRI-AGCM3.2S, Hydrological Research Letters 9(4), 84-89, 2015.